

BELZONA KEEPS HOSPITAL LAUNDRY BILLS DOWN

ID: 140



PROBLEM

Wear and tear in service causes splits, in addition to mechanical damage caused by sharp objects left in clothing (a common occurrence).

APPLICATION SITUATION

Press used to squeeze water from laundry prior to drying. They operate at pressures up to 270 bar.

APPLICATION METHOD

Application was carried out in accordance with Belzona System leaflet VPF-5.

BELZONA FACTS

Typical Belzona repairs cost £10-20 as opposed to a new diaphragm at over £1400. At this hospital some diaphragms have been repaired 5 and 6 times.

INDUSTRY

General Industry

LOCATION

Hospital

APPLICATION DATE

Ongoing since 1994

PRODUCTS

Belzona 2211 (MP Hi-Build Elastomer)

SUBSTRATE

Rubber

PHOTOS

1. The laundry press in operation
2. Typical split prepared and ready to have Belzona applied
3. Completing the Belzona 2211 application

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured under an ISO 9001 Registered Quality Management System.

www.belzona.com

