

# BELZONA UPGRADES MORTUARY FLOOR

ID: 1636



## PROBLEM

As the floor was regularly washed down, it had caused the floor to become damaged and uneven causing water to gather in certain areas.

## APPLICATION SITUATION

The customer required the lifting of the existing floor system and repairing the damaged floor areas, followed by an over-coat of a positive grip system.

## APPLICATION METHOD

Application was carried out in accordance with Belzona Know-How System Leaflets FPA-1 & 8. The Belzona® 4131 was first applied for the repairs to the bases of examination tables, and following this, a dark grey Belzona® 5231 with 15% grey aggregate was applied to give the positive traction system the customer required.

## BELZONA FACTS

The whole application was carried out over one weekend. The low odour, solvent free Belzona products did not impact on the normal activities of the hospital. The Belzona system has provided the hospital with a hygienic, safe and hard wearing floor in the mortuary.

## INDUSTRY

Buildings & Structures

## LOCATION

Hospital Mortuary, Glasgow

## APPLICATION DATE

March 2008

## PRODUCTS

Belzona 4131 (Magma Screed)  
Belzona 5231 (SG Laminate)

## SUBSTRATE

Concrete

## PHOTOS

1. Damaged floor
2. Examination table base screeded with Belzona 4131
3. Floor repairs using Belzona 4131
4. Completed application after application of Belzona 5231

For more examples of Belzona Know-How in Action, please visit [khia.belzona.com](http://khia.belzona.com)

Belzona products are manufactured  
under an ISO 9001 Registered  
Quality Management System.

[www.belzona.com](http://www.belzona.com)

  
**BELZONA®**

Copyright © 1952-2026 Belzona International Limited.