

BELZONA SEALS PLANT ROOM FLOOR

ID: 1637



PROBLEM

Water was leaking through the floor to the operating theatres below.

APPLICATION SITUATION

Boiler plant room of a hospital

APPLICATION METHOD

Application was carried out in accordance with Belzona Know How System Leaflet FPA-8. The floor was first diamond ground and then two coats of Belzona® 5231 (SG Laminate) applied.

BELZONA FACTS

The whole application was carried out over one weekend. The low odour, solvent free Belzona® 5231 did not impact on normal operating of the hospital.

INDUSTRY

Buildings & Structures

LOCATION

Hospital, UK

APPLICATION DATE

May 2009

PRODUCTS

Belzona 5231 (SG Laminate)

SUBSTRATE

Concrete

PHOTOS

Damaged floor Belzona 5231 application
starting Completed application
Completed application

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured
under an ISO 9001 Registered
Quality Management System.

www.belzona.com

