

BELZONA PROVIDES SAVINGS BY SEALING FLOOR

ID: 5349



PROBLEM

The seams on the floor in the large animal surgery room had split open, allowing bacteria to flourish underneath. The floor had to be sealed.

APPLICATION SITUATION

Large animal surgery room.

APPLICATION METHOD

The floor was cleaned and disinfected, and then allowed to dry. A roughing tool was used to abrade the surface. Belzona 2911 was applied and allowed to cure. The area was masked off and Belzona 2221 was brushed on with Belzona 9341 to bridge the seam. The application was carried out in accordance with a modified version of Belzona Know-How System Leaflet FPA-6.

BELZONA FACTS

Belzona solved the problem in a very cost-effective manner. The only alternative solution was a complete replacement of the flooring, which was deemed too expensive.

INDUSTRY

Buildings & Structures

LOCATION

WA, USA

APPLICATION DATE

1992

PRODUCTS

Belzona 2221 (MP Fluid Elastomer)
Belzona 2911 (Elastomer QD Conditioner)
Belzona 9341 (Reinforcing Sheet)

SUBSTRATE

Urethane

PHOTOS

1. Drying the floor after cleaning
2. Abrading the surface
3. Applying Belzona 2221 over the seams
4. Completed application

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured
under an ISO 9001 Registered
Quality Management System.

www.belzona.com

Copyright © 1952-2026 Belzona International Limited.


BELZONA®