

REPAIR AND PROTECTION OF HOSPITAL LAUNDRY FLOOR WITH BELZONA

ID: 1523



PROBLEM

The laundry floor of this hospital was not level and water was gathering in the middle of the floor. They needed the floor to be re-levelled so that water ran to the drains. The floor also had to be safe from accidents.

APPLICATION SITUATION

Uneven laundry floor of hospital

APPLICATION METHOD

Application was carried out in accordance with Belzona Know-How System Leaflet FPA-1. Existing floor was cut out to create a fall and then screeded over with Belzona® 4131. This was then overcoated with Belzona® 5231.

BELZONA FACTS

The use of Belzona® 4131 allowed falls to be created with minimum disruption to hospital operations. the Belzona® 5231 provided a safe surface for operatives in the laundry. The hospital are now currently looking at improving the safety throughout the building utilising Belzona solutions.

INDUSTRY

Buildings & Structures

LOCATION

Hospital, Scotland

APPLICATION DATE

Oct/ Nov 2009

PRODUCTS

Belzona 4131 (Magma-Screed) Belzona 5231 (SG Laminate)

SUBSTRATE

Concrete

PHOTOS

Uneven, damaged laundry floor
Application of Belzona 4131
Application of Belzona 4131 Completed application

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured under an ISO 9001 Registered Quality Management System.

www.belzona.com

