

BELZONA 4000 SERIES FLOOR COATING FOR A STERILIZING ROOM

ID: 378



PROBLEM

Floor was spalled, cracked and and therefore non-compliant with sanitary requirements.

APPLICATION SITUATION

Floor in a sanitizer room - 100° F at 80% humidity.

APPLICATION METHOD

The application was carried out in accordance with a modified version of Belzona Know-How System Leaflet FPA-3. Shot-blasted floor, followed by thorough cleaning. Roller/brush application of product in a slurry-grade.

BELZONA FACTS

This customer had put the repair out for bid. The Belzona Solution was over seven times more expensive than the other bids received. Because of the aggressive environment and heavy fork lift traffic, only the Belzona System provided the protection required. Tenacity and great care taken in understanding and appreciating the customer's problem led them to believe in the Belzona Solution.

INDUSTRY

General Industry

LOCATION

Medical Sanitizers - Minnesota U.S.A.

APPLICATION DATE

March 2002

PRODUCTS

Belzona 4151 (Magma-Quartz Resins)

SUBSTRATE

Concrete

PHOTOS

1. Final steps of surface preparation
2. In progress
3. Job complete

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured under an ISO 9001 Registered Quality Management System.

www.belzona.com



Copyright © 1952-2026 Belzona International Limited.