

BELZONA UPGRADES PLANT ROOM FLOOR

ID: 8318



PROBLEM

The area of the plant being extended was likely to be exposed to spillages in the future and therefore caused potential health and safety concerns for the workers.

APPLICATION SITUATION

A Pharmaceutical plant was expanding a section of the plant and wanted a protective flooring system installed.

APPLICATION METHOD

This application was carried out in accordance with Belzona system leaflet FPA-03. The new concrete where the plant room was being extended was ground, cleaned and any loose contaminants were removed from the surface of the concrete. Once the concrete was prepared the Belzona 5231 was applied using rollers.

BELZONA FACTS

The client said the Belzona material was extremely easy to mix and apply with the rollers and the Belzona system had the benefit of having an aggregate incorporated into the flooring system, this meant the floor acted as a positive grip system making it safe for the workers.

INDUSTRY

Buildings & Structures

LOCATION

Italy

APPLICATION DATE

2016

PRODUCTS

Belzona 5231 (SG Laminate)

SUBSTRATE

Concrete

PHOTOS

1. Before application - Extension of plant room
2. Before application
3. Belzona 5231 being applied by rollers
4. Final application

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured under an ISO 9001 Registered Quality Management System.

www.belzona.com

