

SMOOTH RIDE EXPANSION JOINT

ID: 9469



PROBLEM

The aluminum cover plate creates an uncomfortable jolt to patients being transported in beds and wheelchairs, as well as a trip hazard for pedestrians.

APPLICATION SITUATION

The entire remediation was accomplished in one day, with the area returned to full traffic the following morning. The staff were so pleased that their patients would not have to endure this constant irritant anymore, that they immediately started identifying other areas needing the same attention.

APPLICATION METHOD

Diamond grinders and HEPA vacuums were utilized during surface preparation. The Belzona 4131 was hand troweled to ensure the transition was "smooth" and level and top coated with Belzona 4411. The joint was sealed with Belzona 2221.

BELZONA FACTS

The renovation was accomplished by isolating the affected joint with sheet plastic and rerouting patient and staff traffic around the work area for the afternoon. As the Belzona is low odor, no other disruption was experienced in this busy treatment area of the hospital. Belzona has remediated approximately 20 expansion joints at this hospital alone in the last few years.

INDUSTRY

Buildings & Structures

LOCATION

Kansas City

APPLICATION DATE

March 2024

PRODUCTS

Belzona 2221 (MP Fluid Elastomer)
Belzona 2911 (Elastomer QD Conditioner)
Belzona 4131 (Magma-Screed)
Belzona 4411 (Granogrip)
Belzona 4911 (Magma TX Conditioner)

SUBSTRATE

Concrete

PHOTOS

1. Area Veteran's hospital
2. Aluminum cover plate causing bump and trip hazard
3. Plate removed and condition of underlying joint
4. Completely re-engineered and rebuilt smooth ride joint

For more examples of Belzona Know-How in Action, please visit khia.belzona.com

Belzona products are manufactured under an ISO 9001 Registered Quality Management System.

www.belzona.com

